

# Illustrated Quick Guide

## How to place the tree:

1. Cut the trunk of crosswise, if not delivered with a clean cut. Remove the bottom brakes from the trunk, up to 8 - 10 inches.



2. On the Super Grip, turn the ring clockwise until it stops. Now the Super Grip is in start position.



3. Place the trunk on the edge of the springs, then position the tree vertically.



4. Push the tree half way down. You can still adjust the tree in this stadium. When satisfied, push the tree to the bottom of the Super Grip.



5. Then, lift the tree (the Super Grip is now connected to the tree trunk) and give it a **gentle** push against the floor, to be sure the spike goes into the trunk.



6. Your tree is now in place, fill the watertank and you are ready to decorate your tree.



Fill the watertank.  
Check out more info on CD.

## How to take the tree out:

7. Turn the tree counterclockwise. The springs releases the tree from the Super Grip, and you can lift the tree out.



## User`s Manual

### Super Grip Big Model

Super Grip is extremely easy to use. In the following you will find the basic procedures which will ensure you a successful use and many years of satisfaction with a new product. Please read the following instructions carefully, before you start to use the Super Grip.

The Christmas tree stand Super Grip is constructed for trees with a max height of 3 metres

(10 feet) and with a diameter at the cut level reaching from 4 to 15 centimetres.(max 6 Inch)

The stand is only suitable for indoor use. The insertion of the tree and the handling of the stand should only be executed by adults.

The Christmas tree must be cut horizontally (square cut) and 20 – 25 centimetres

( 8 – 10 Inches ) of the lower part of the trunk must be clean of branches before insertion into the stand.

The stand must be placed on a floor protection (e.g. tree skirt).

Before you insert the tree make sure that the fastening device is placed in the start position. The illustration is indicating the start position.

If the fastening device is not in the start position the spring holders must be tilted inwards and together with the movable ring (to which they are connected) be turned clockwise until indicated start position. In handling the spring holders make sure only to touch the plastic part to avoid injuries.

Start inserting the tree into the stand until just above the nail, which is placed in the bottom of

# Super<sup>TM</sup> Grip

**BIG  
MODEL**

the water reservoir, adjust the vertical position, lift the tree 3-4 centimetres and lower the tree forcefully against the floor, thus securing that the nail will enter deeply into the wooden trunk.

**When the insertion is completed you should fill up the water reservoir. Depending the size of the trunk in diameter, it will take up to 6 litre.( 1,5 Gallon ) Pour the water into the stand, throw the opening to the water reservoir. Fill the reservoir with regularity. When it is full, excessive water will overflow and enter into the three groove-ditches on the outside of the stand at floor level. Stop the filling 5 mm (0,2 inch) before the edge, ditches are only present to protect the floor from water spill.**

Make sure that there has not become any damage on the water reservoir, and make sure there is no leak before you live the tree.

To disconnect the tree from the stand is very simple: hold the tree with one hand, the arm fully stretched out and place the tip of your foot into the groove just above the spill water ditch. Turn the tree counter clockwise as indicated by the arrow and the word "open" until the fastening springs are released from the trunk. Now you can remove the tree from the stand simply by lifting it vertically.

The stand can be cleaned simply by using a mild household soap.

Attention! Do not let candles burn on the tree unless under continuous observation by adults.

By disregarding the above-described directions for use, any guarantee claim will not be valid.

Illustration: Please see the front page.

### Nordic Innovation AS

Bergelandsgaten 42  
4012 Stavanger  
Norway

Phone: +47 51 53 26 60

Mob: +47 90 56 54 07

E-mail: [alf@supergrip.com](mailto:alf@supergrip.com)



**Nordic Innovation**